



NOTES:

Jumper JPL is wired in position 1 (Rev-08) on the board by a default trace. To use a different jumper position, please refer to the component list and use the jumper as indicated in the JPL column. Prior to component installation, install or omit jumper as indicated in the JPL column.

RECORD EQ TYPE	C53	C54	C55	C56	JPL	CUT
<01> 7.5 NMB/IEC2 (50/3180US) - 15 IPS NMB/IEC2 (50/3180US)	<H463> 215-790 pF	<H463> 75-380 pF	omit	omit	2	X
<02> 3.75 NMB/IEC/ElA (90/3180US) - 7.5 IPS NMB/IEC2 (50/3180US)	<H4611> 300-1180 pF	<H463> 215-790 pF	omit	omit	none	X
<03> 7.5 IPS CCIR/IECI (70US/1mf) - 15 IPS CCIR/IECI (35US/1mf)	<H463> 215-790 pF	<H463> 75-380 pF	3.3	3.3	none	X
<04> 15 IPS NMB/IEC2 (50/3180US) - 30 IPS NCS (17.5US/1mf)	<H463> 75-380 pF	<H464> 45-280 pF	omit	3.3	1	X
<04> 3.75 NMB/IEC/ElA (90/3180US) - 7.5 IPS CCIR/IECI (70US/1mf)	<H4611> 300-1180 pF	<H463> 215-790 pF	omit	3.3	none	X
<06> 15 IPS CCIR/IECI (35US/1mf) - 30 IPS NCS (17.5US/1mf)	<H463> 75-380 pF	<H464> 45-280 pF	3.3	3.3	none	X

APPROVALS	RTZ AUDIO Professional Audio	NO. Rev: 872 6/29/98 TEL: 720-346-9794
DRAWN	RECORD EQUALIZER	
RES	CopyRight (C) 1999 RTZ Audio	
CHECKED	DATE: 6/03/2000 12:49:04a	REV. A
RES	DATE: 12/29/98	
	FILE: rec-eq	SHEET: 1/1